

The logo for the CR1 Racing Team is a rectangular badge with a white background and a double border of red and green. It features the letters 'CR' in black, followed by a large red '1' with a green outline. To the right, the words 'RACING TEAM' are written in black, stacked vertically.

SPARE PARTS CATALOG CATALOGUE RECHANGES ERSATZTEILKATALOG

+ VARIANTS! '89




TUAREG

Wind
50

1988







POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Telaio verniciato bianco	Frame	82 32 239	82 32 239	82 32 239	82 32 239
2	Molla ritorno pedana	Spring	81 01 317	81 01 317	81 01 317	81 01 317
3	Gomma copri pedana pilota	Rubber	81 20 289	81 20 289	81 20 289	81 20 289
4	Bussola distanziale	Spacer	81 20 307	81 20 307	81 20 307	81 20 307
5	Pedana dx zinc. nera	Foot rest (R)	81 32 239	81 32 239	81 32 239	81 32 239
6	Pedana sx zinc. nera	Foot rest (L)	81 32 241	81 32 241	81 32 241	81 32 241
7	Vite Tepf M10 x 30	Screw	81 52 048	81 52 048	81 52 048	81 52 048
8	Molla ritorno cavalletto	Spring	82 01 002	82 01 002	82 01 002	82 01 002
9	Cavalletto laterale vern. bianco	Lateral stand	82 32 219	82 32 219	82 32 219	82 32 219
10	Piastra silent-block radiatore	Holder	81 01 397	81 01 397	81 01 397	81 01 397
11	Fascetta elastica D. 9,1	Collar	81 01 731	81 01 731	81 01 731	81 01 731
12	Gommino	Rubber	81 20 030	81 20 030	81 20 030	81 20 030
13	Bussola distanziale	Spacer	81 20 253	81 20 253	81 20 253	81 20 253
14	Silent block inferiore	Silent block	81 20 275	81 20 275	81 20 275	81 20 275
15	Tappo serbatoio olio	Plug	81 20 354	81 20 354	81 20 354	81 20 354
16	Fascetta clic D.22 x 8,6	Collar	82 01 169	82 01 169	82 01 169	82 01 169
17	Fascetta clic D. 26 x 8,6	Collar	82 01 170	82 01 170	82 01 170	82 01 170
18	Radiatore acqua	Radiator	82 01 259	82 01 259	82 01 259	82 01 259
19	Tubo acqua pompa-radiatore	Radiator water pipe pump	82 20 145	82 20 145	82 20 145	82 20 145
20	Tubo acqua radiatore-testa motore	Radiator water pipe cilinder	82 20 146	82 20 146	82 20 146	82 20 146
21	Vaso espansione	Expansion tank	82 30 077	82 30 077	82 30 077	82 30 077
22	Guarnizione tappo vaso di espansione	Gasket	82 20 191	82 20 191	82 20 191	82 20 191
23	Serratura casco	Helmet lock	81 01 425	81 01 425	81 01 425	81 01 425
24	Gommino attacco serbatoio	Rubber	82 01 291	82 01 291	82 01 291	82 01 291
25	Rotella tendicatena	Chain puller roller	81 01 375	81 01 375	81 01 375	81 01 375
26	Bussola distanziale	Spacer	81 01 377	81 01 377	81 01 377	81 01 377
27	Piastra fissaggio cruscotto vern. nera	Parcel grid shoulder	81 32 552	81 32 552	81 32 552	81 32 552
28	Telaio supporto carena verniciato	Screw	82 32 245	82 32 245	82 32 245	82 32 245
29	Tappo radiatore	Plug	81 01 384 ⁵²⁶	81 01 384 ⁵²⁶	81 01 384 ⁵²⁶	81 01 384 ⁵²⁶
30	Gommino attacco cruscotto	Rubber	81 20 470	81 20 470	81 20 470	81 20 470
31	Bussola montaggio sella	Bush	82 21 056	82 21 056	82 21 056	82 21 056
32	Gommino passafilo	Rubber	81 20 405	81 20 405	81 20 405	81 20 405




CENTRO RICAMBI SRL
 via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
 TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
 e-mail: cr1firenze@tiscali.it



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Serbatoio vern.	Fuel tank	82 30 329	82 30 330	82 30 329	82 30 330
2	Tappo serbatoio benzina	Fuel tank cap	81 01 863	81 01 863	81 01 863	81 01 863
3	Rubinetto benzina riserva elettrica	Fuel cock	82 01 273	82 01 273	82 01 273	82 01 273
4	Bussola distanziale	Bush	82 21 052	82 21 052	82 21 052	82 21 052
5	Gommino	Rubber	81 20 311	81 20 311	81 20 311	81 20 311
6	Gommino	Rubber	81 20 001	81 20 001	81 20 001	81 20 001
7	Clips fissaggio batteria	Clips	81 01 689	81 01 689	81 01 689	81 01 689
8	Rivetto plastica nero	Rivet	81 20 318	81 20 318	81 20 318	81 20 318
9	Cupolino	Front cowling	82 30 268	82 30 268	82 30 268	82 30 268
10	Protezione piastra forcella	Plastic guard	82 30 280	82 30 280	82 30 280	82 30 280
11	Rete protezione radiatore bianca	Protection guard	82 30 281	82 30 281	82 30 281	82 30 281
12	Carena completa verniciata	Fairing compl.	82 30 286	82 30 318	82 30 286	82 30 318
13	Gommino con inserto filettato M5	Rubber with bush	81 20 531	81 20 531	81 20 531	81 20 531
14	Rete doppi fari	Headlight screen	82 30 314	82 30 316	82 30 314	82 30 316
15	Parafango anteriore completo vern. bianco	Front mudguard	82 30 282	82 30 282	82 30 282	82 30 282
16	Fiancatina dx vern.	Side panel (R)	82 30 276	82 30 323	82 30 276	82 30 323
17	Fiancatina sx vern.	Side panel (L)	82 30 278	82 30 324	82 30 278	82 30 324
18	Paracoppa grigio	Engine guard	82 01 267	82 01 267	82 01 267	82 01 267
19	Sella	Seat	82 29 038	82 29 045	82 29 038	82 29 045
20	Borsetto	Gloves case	82 01 268	82 01 293	82 01 268	82 01 293
21	Trousse attrezzi	Tool box	82 01 152	82 01 152	82 01 152	82 01 152
22	Gommino	Rubber	81 20 030	81 20 030	81 20 030	81 20 030
23	Serbatoio olio completo	Oil tank	82 30 307	82 30 307	82 30 307	82 30 307
24	Tappo serbatoio olio	Oil tank plug	81 20 354	81 20 354	81 20 354	81 20 354
25	Guarnizione tappo serbatoio olio	Gasket, oil tank plug	81 20 355	81 20 355	81 20 355	81 20 355
26	Indicatore riserva olio	Oil feeler	81 12 289	81 12 289	81 12 289	81 12 289
27	Parafango posteriore completo nero	Rear mudguard	82 30 288	82 30 288	82 30 288	82 30 288
28	Codino verniciato bianco	Rear cowling	82 30 304	82 30 304	82 30 304	82 30 304
29	Bussola per codino	Bush	82 21 050	82 21 050	82 21 050	82 21 050
30	Piastra gommini per codino nera	Plate	82 30 306	82 30 306	82 30 306	82 30 306
31	Fascetta elastica D.10	Collar	81 01 595	81 01 595	81 01 595	81 01 595
32	Fascetta 7-11 H5	Collar	82 01 166	82 01 166	82 01 166	82 01 166
33	Bussola distanziale	Spacer	81 21 041	81 21 041	81 21 041	81 21 041
34	Decalco (serie)	Decal (set)	82 11 482	82 11 492	82 11 483	82 11 491
35	Decalco carena (serie) + serbatoio	Fairing decal (set)	82 11 474	82 11 453	82 11 486	82 11 468
36	Decalco fianc. e paraf. ant. portapac. (serie)	Side panel decal (set)	82 11 477	82 11 460	82 11 477	82 11 460




POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Peso antivibrante vern. nero	Unvibrating weight	81 01 555	81 01 555	81 01 555	81 01 555
2	Specchio retrovisore tipo omologato	Driving mirror	81 01 771	81 01 771	81 01 771	81 01 771
3	Manubrio verniciato nero metallizzato	Handle bar	82 18 078	82 18 078	82 18 078	82 18 078
4	Paramani dx-sx bianchi forati	Hand guard	82 30 272	82 30 272	82 30 272	82 30 272
5	Comando gas comp. di manopole forate	Throttle cable	82 18 047	82 18 047	82 18 047	82 18 047
6	Bussola distanziale paramani	Bush	81 21 080	81 21 080	81 21 080	81 21 080
7	Cruscotto comp. cablaggio e lampade	Dash board	82 12 112	82 12 112	82 12 112	82 12 112
8	Cablaggio cruscotto senza lampade	Dash board wiring harness	82 12 106	82 12 106	82 12 106	82 12 106
9	Parte sup. crusc. nuda verniciata	Dash board (upper)	81 30 299	81 30 299	81 30 299	81 30 299
10	Parte inf. crusc. nuda verniciata	Dash board (lower)	81 30 290	81 30 290	81 30 290	81 30 290
11	Rinvio contakm ad angolo	Speedometer gear	81 01 761	81 01 761	81 01 761	81 01 761
12	Azzeratore contakm crusc. completo	Trip odometer knob	81 12 351	81 12 351	81 12 351	81 12 351
13	Pulsante check crusc. completo	Chech knob	81 12 352	81 12 352	81 12 352	81 12 352
14	Spia neutral serigrafata cruscotto	Indicator light neutral	81 30 292	81 30 292	81 30 292	81 30 292
15	Manopole coppia (dx-sx)	Handle grip (pair)	81 17 045	81 17 045	81 17 045	81 17 045
16	Registro cavo acceleratore	Throttle adjuster cable	81 18 101	81 18 101	81 18 101	81 18 101
17	Cappuccio registro gas	Cap throttle cable	81 20 270	81 20 270	81 20 270	81 20 270
18	Cavo gas nero	Gas cable	82 14 023	82 14 023	82 14 023	82 14 023
19	Comando frizione completo	Clutch control compl.	82 18 056	82 18 056	82 18 056	82 18 056
20	Leva frizione nuda	Clutch lever bare	82 18 061	82 18 061	82 18 061	82 18 061
21	Vite leva frizione con dado	Screw with nut	82 18 060	82 18 060	82 18 060	82 18 060
22	Registro leva frizione	Clutch adjuster lever	81 18 104	81 18 104	81 18 104	81 18 104
23	Copriregistro frizione	Lever cover	81 20 271	81 20 271	81 20 271	81 20 271
24	Bussola distanziale	Spacer	81 21 037	81 21 037	81 21 037	81 21 037
25	Pompa freno anteriore	Front master cylinder	82 13 099	82 13 099	82 13 099	82 13 099
26	Leva freno anteriore nuda	Front brake lever	82 18 074	82 18 074	82 18 074	82 18 074
27	Grano speciale con dado	Dowel and nut	82 13 069	82 13 069	82 13 069	82 13 069
28	Cavallotto	U-bolt	82 13 078	82 13 078	82 13 078	82 13 078
29	Vite leva pompa	Screw	81 13 158	81 13 158	81 13 158	81 13 158
30	Coperchio serbatoio	Brake pump cover	82 30 240	82 30 240	82 30 240	82 30 240
31	Guarnizioni pompa freno ant. (serie)	Pump gasket (set)	82 13 079	82 13 079	82 13 079	82 13 079
32	Pistoncino	Pump piston	82 13 079	82 13 079	82 13 079	82 13 079
33	Cavo frizione nero	Clutch cable	82 14 025	82 14 025	82 14 025	82 14 025
34	Trasmissione contagiri	Tachometer cable	82 14 044	82 14 044	82 14 044	82 14 044
35	Trasmissione contakm	Speedometer cable	82 14 046	82 14 046	82 14 046	82 14 046
36	Bloccetto commutatore - bloccasterzo	Main switch	82 01 194	82 01 194	82 01 194	82 01 194



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Forcellone verniciato bianco	Rear swing arm	82 32 241	82 32 241	82 32 241	82 32 241
2	Bussola di rotazione forcellone	Bush	82 21 008	82 21 008	82 21 008	82 21 008
3	Bussola distanziale	Bush	82 32 115	82 32 115	82 32 115	82 32 115
4	Anello di tenuta	O ring	82 20 095	82 20 095	82 20 095	82 20 095
5	Perno forcellone completo	Rear swing arm pin	82 05 063	82 05 063	82 05 063	82 05 063
6	Piastrina post. forcellone	Rear plate	81 34 029	81 34 029	81 34 029	81 34 029
7	Piastrina tendicatena (dx-sx)	Chain tightener plate (R.L.)	81 34 030	81 34 030	81 34 030	81 34 030
8	Biella singola	Connecting rod	82 32 244	82 32 244	82 32 244	82 32 244
9	Vite TCEI M 8 x 110	Screw	81 52 024	81 52 024	81 52 024	81 52 024
10	Biella doppia completa	Connecting rod	82 32 271	82 32 271	82 32 271	82 32 271
11	Biella singola verniciata	Connecting rod single	82 32 244	82 32 244	82 32 244	82 32 244
12	Spinotto sospensione post.	Bush	82 21 053	82 21 053	82 21 053	82 21 053
13	Spinotto biella doppia ammortizzatore	Bush	82 21 049	82 21 049	82 21 049	82 21 049
14	Rondella spallam. biella doppia	Washer	82 20 206	82 20 206	82 20 206	82 20 206
15	Rondella spall. biella ammortizzatore	Washer	82 20 203	82 20 203	82 20 203	82 20 203
16	Gabbia a rullini	Bearing	81 10 049	81 10 049	81 10 049	81 10 049
17	Guscio a rullini	Bearing	82 10 008	82 10 008	82 10 008	82 10 008
18	Anello di tenuta	O ring	81 20 559	81 20 559	81 20 559	81 20 559
19	Ammortizzatore	Shock absorber	82 03 267	82 03 267	82 03 267	82 03 267
20	Vite TE M10 x 38	Screw	81 52 144	81 52 144	81 52 144	81 52 144
21	Carter catena	Chain cover	82 30 087	82 30 087	82 30 087	82 30 087
22	Scodellino per pattino guidacatena	Cup	82 34 020	82 34 020	82 34 020	82 34 020
23	Pattino guida catena nero	Chain guide plate	82 20 209	82 20 209	82 20 209	82 20 209
24	Cruna catena nera	Chain sliding shoe	82 30 088	82 30 088	82 30 088	82 30 088




CENTRO RICAMBI ^{SRL}
 via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
 TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
 e-mail: cr1firenze@tiscali.it



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Motore completo	Engine	82 22 078	82 22 078	82 22 082	82 22 082
2	Leva avviamento nera	Starting lever	82 22 015	82 22 015	82 22 015	82 22 015
3	Leva cambio	Gearbox lever	82 22 115	82 22 115	82 22 115	82 22 115
4	Gommino leva cambio	Rubber	82 20 205	82 20 205	82 20 205	82 20 205
5	Pipetta candela	Spark plug cap	82 20 179	82 20 179	82 20 179	82 20 179
6	Marmitta verniciata	Exhaust pipe	82 19 058	82 19 058	82 19 058	82 19 058
7	Silenziatore	Silencer	82 19 059	82 19 059	82 19 059	82 19 059
8	Manicotto marmitta-silenziatore	Exhaust pipe coupling	82 20 003	82 20 003	82 20 003	82 20 003
9	Molla fissaggio marmitta	Spring	81 01 259	81 01 259	81 01 259	81 01 259
10	Silent block	Silent block	81 20 439	81 20 439	81 20 439	81 20 439
11	Silent block	Silent block	81 01 285	81 01 285	81 01 285	81 01 285
12	Rondella spall. silent-block	Washer	81 01 284	81 01 284	81 01 284	81 01 284
13	Bussola distanziale	Spacer	81 21 028	81 21 028	81 21 028	81 21 028
14	Coperchio cassa filtro	Filter air box cover	82 30 037	82 30 037	82 30 037	82 30 037
15	Paratia cassa filtro	Filter box cover protection	81 30 141	81 30 141	81 30 141	81 30 141
16	Rete supporto filtro	Filter net	82 30 017	82 30 017	82 30 017	82 30 017
17	Filtro	Filter	82 01 111	82 01 111	82 01 111	82 01 111
18	Base cassa filtro	Air filter box base	82 30 092	82 30 092	82 30 092	82 30 092
19	Manicotto carburatore-cassa filtro	Carburetor coupling	82 20 180	82 20 180	82 20 180	82 20 180
20	Fascetta 47-67 HS	Clamp	81 01 520	81 01 520	81 01 520	81 01 520
21	Carburatore SHA 14-12	Carburetor	82 06 013	82 06 013	82 06 013	82 06 013




CENTRO RICAMBI^{SRL}
 via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
 TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
 e-mail: cr1firenze@tiscali.it



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Ruota anteriore (5-13-12-4-10-11)	Front wheel compl.	82 08 146	82 08 146	82 08 146	82 08 146
2	Spessore	Spacer	82 25 140	82 25 140	82 25 140	82 25 140
3	Perno ruota	Front axle	82 13 100	82 13 100	82 13 100	82 13 100
4	Cerchio D.21" cromato	Rim	82 08 163	82 08 163	82 08 163	82 08 163
5	Corpo mozzo anteriore rosso	Front hub	82 25 183	82 25 183	82 25 183	82 25 183
6	Camera d'aria anteriore	Front air tube	82 09 005	82 09 005	82 09 005	82 09 005
7	Copertura anteriore	Front tyre	82 09 009	82 09 009	82 09 009	82 09 009
8	Flap per ruota da 21"	Front wheel strip	82 09 033	82 09 033	82 09 033	82 09 033
9	Nipples D.3	Nipples	82 08 003	82 08 003	82 08 003	82 08 003
10	Raggio D3 x 240 C.90° collo 3	Spoke	82 08 150	82 08 150	82 08 150	82 08 150
11	Raggio D3 x 240 C.95° collo 3,5	Strip	82 08 151	82 08 151	82 08 151	82 08 151
12	Cuscinetto mozzo posteriore	Bearing	82 25 118	82 25 118	82 25 118	82 25 118
13	Distanziale cuscinetti	Spacer	81 10 003	81 10 003	81 10 003	81 10 003
14	Vite TBEI M6 x 18	Screw	81 52 101	81 52 101	81 52 101	81 52 101
15	Disco freno anteriore	Front brake disk	82 13 083	82 13 083	82 13 083	82 13 083
16	Pinza freno anteriore	Caliper, front brake	82 13 098	82 13 098	82 13 098	82 13 098
17	Spurgo aria	Air bleeder cup	81 13 006	81 13 006	81 13 006	81 13 006
18	Coppia pastiglie	Pair of pads	82 25 124	82 25 124	82 25 124	82 25 124
19	Serie anelli di tenuta	O ring set	82 25 125	82 25 125	82 25 125	82 25 125
20	Coppia pistoncini	Pair of pistons	82 13 018	82 13 018	82 13 018	82 13 018
21	Perni e molla	Pins and spring	82 13 029	82 13 029	82 13 029	82 13 029
22	Coperchio pinza	Caliper cover	82 13 021	82 13 021	82 13 021	82 13 021
23	Cappuccio spurgo aria	Air bleeder cap	81 13 005	81 13 005	81 13 005	81 13 005
24	Rinvio contachilometri	Gear	82 01 272	82 01 272	82 01 272	82 01 272
25	Tubo flessibile freno anteriore	Brake oil pipe	82 13 084	82 13 084	82 13 084	82 13 084
26	Vite fiss. tubo olio	Screw	81 13 003	81 13 003	81 13 003	81 13 003
27	Rondella in rame	Washer	81 13 004	81 13 004	81 13 004	81 13 004


CENTRO RICAMBI^{SRL}
via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
e-mail: cr1firenze@tiscali.it




CR1
RACING TEAM

POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Ruota posteriore (2-30-29-4-6-7)	Rear wheel	82 08 165	82 08 165	82 08 165	82 08 165
2	Corpo mozzo posteriore rosso	Rear hub body	82 25 192	82 25 192	82 25 192	82 25 192
3	Perno	Rear axle	82 25 163	82 25 163	82 25 163	82 25 163
4	Cerchio D.18" cromato	Rim	82 08 164	82 08 164	82 08 164	82 08 164
5	Nipples D.3	Nipples	82 08 003	82 08 003	82 08 003	82 08 003
6	Raggio D.3 x 196 C. 80° collo 8,1	Spoke	82 08 125	82 08 125	82 08 125	82 08 125
7	Raggio D.3 x 196 C. 92° collo 5,5	Spoke	82 08 127	82 08 127	82 08 127	82 08 127
8	Copertura posteriore	Rear Tyre	82 09 016	82 09 016	82 09 016	82 09 016
9	Camera d'aria posteriore	Rear air tube	82 09 018	82 09 018	82 09 018	82 09 018
10	Flap per ruota da 18"	Strip rear wheel	82 09 032	82 09 032	82 09 032	82 09 032
11	Disco freno posteriore	Rear brake disk	82 13 031	82 13 031	82 13 031	82 13 031
12	Leva freno post. vern. nera	Rear brake lever	82 32 123	82 32 123	82 32 123	82 32 123
13	Anello di tenuta	O ring	82 20 149	82 20 149	82 20 149	82 20 149
14	Bussola di rotazione leva freno	Bush	82 21 010	82 21 010	82 21 010	82 21 010
15	Bussola di rotazione leva freno	Bush	82 21 014	82 21 014	82 21 014	82 21 014
16	Molla ritorno freno posteriore	Rear brake return spring	82 21 022	82 21 022	82 21 022	82 21 022
17	Corona Z = 44 (Pignone 2.12)	Crown	82 07 022	82 07 022	82 07 022	82 07 022
18	Catena comp. di maglia di giunzione	Chain compl. with connect. link	82 07 017	82 07 017	82 07 017	82 07 017
19	Maglia di giunzione	Connecting link	82 07 019	82 07 019	82 07 019	82 07 019
20	Piastrina di sicurezza con 2 fori	Lock plate - 2 holes	82 25 144	82 25 144	82 25 144	82 25 144
21	Piastrina di sicurezza con 3 fori	Lock plate - 2 holes	82 25 145	82 25 145	82 25 145	82 25 145
22	Pompa freno posteriore	Master cylinder	82 13 082	82 13 082	82 13 082	82 13 082
23	Snodo sferico M6	Ball joint	82 10 007	82 10 007	82 10 007	82 10 007
24	Asta pompa freno	Rear brake rod	82 13 088	82 13 088	82 13 088	82 13 088
25	Serbatoio olio completo	Oil tank compl.	82 13 086	82 13 086	82 13 086	82 13 086
26	Tubo flessibile freno posteriore	Rear oil pipe	82 13 085	82 13 085	82 13 085	82 13 085
27	Piastra ancoraggio pinza	Anchor plate	82 34 015	82 34 015	82 34 015	82 34 015
28	Pinza freno posteriore	Rear brake caliper	82 13 081	82 13 081	82 13 081	82 13 081
29	Cuscinetto mozzo posteriore	Rear hub bearing	82 25 118	82 25 118	82 25 118	82 25 118
30	Bussola distanziale	Spacer	82 25 142	82 25 142	82 25 142	82 25 142
31	Distanz. int. piastra pinza posteriore	Spacer	81 21 088	81 21 088	81 21 088	81 21 088
32	Distanz. est. piastra pinza posteriore	Spacer	81 21 089	81 21 089	81 21 089	81 21 089
33	Guarnizioni con piston. pompa freno post.	Rear pump gasket	82 13 105	82 13 105	82 13 105	82 13 105
34	Raccordo pompa freno post.	Rear pipe connection	81 13 157	81 13 157	81 13 157	81 13 157
35	Cuffia protezione asta pompa fr. post.	Rear dust cover	82 13 107	82 13 107	82 13 107	82 13 107
36	Serie guarnizioni pinza freno	Rear caliper gasket	82 13 102	82 13 102	82 13 102	82 13 102


POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
37	Coppia pistoncini pinza freno	Pistons rear caliper	82 13 103	82 13 103	82 13 103	82 13 103
38	Coppia pastiglie	Pads	82 13 104	82 13 104	82 13 104	82 13 104
39	Spurgo pinza freno post.	Rear caliper bleeder	82 13 108	82 13 108	82 13 108	82 13 108
40	Perno pastiglie pinza freno posteriore	Upper cover disk	82 13 109	82 13 109	82 13 109	82 13 109
41	Paradisco posteriore parte inf.	Disk cover (lower)	82 30 266	82 30 266	82 30 266	82 30 266
42	Paradisco posteriore parte sup.	Disk cover (upper)	82 30 267	82 30 267	82 30 267	82 30 267
43	Bussola distanziale	Spacer	82 25 138	82 25 138	82 25 138	82 25 138






POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Forcella	Front fork	82 03 244	82 03 244	82 03 244	82 03 244
2	Anello parapolvere inferiore	Lower, dust cover	81 01 271	81 01 271	81 01 271	81 01 271
3	Anello supporto parapolvere	Ring, dust cover	81 01 272	81 01 272	81 01 272	81 01 272
4	Cuscinetto a rulli	Roller bearing	81 10 024	81 10 024	81 10 024	81 10 024
5	Cuscinetto a sfere	Ball	81 10 025	81 10 025	81 10 025	81 10 025
6	Parapolvere superiore	Upper dust	81 20 211	81 20 211	81 20 211	81 20 211
7	Supporto dx paraf. ant. anodizzato	Support	81 32 666	81 32 666	81 32 666	81 32 666
8	Supporto sx paraf. ant. anodizzato	Support	81 32 667	81 32 667	81 32 667	81 32 667
9	Cavallotto manubrio	U bolt	82 03 249 198	82 03 249 198	82 03 249 198	82 03 249 198
10	Piastra superiore	Upper plate	82 03 250	82 03 250	82 03 250	82 03 250
11	Dado fissaggio canotto	Nut	82 03 251	82 03 251	82 03 251	82 03 251
12	Rondella dado fissaggio canotto	Washer	82 03 252	82 03 252	82 03 252	82 03 252
13	Piastra inferiore con canotto	Lower plate	82 03 253	82 03 253	82 03 253	82 03 253
14	Fodero	Fork leg	82 03 254	82 03 254	82 03 254	82 03 254
15	Stelo	Tube	82 03 255	82 03 255	82 03 255	82 03 255
16	Fondello sx	Hub (L)	82 03 256	82 03 256	82 03 256	82 03 256
17	Fondello dx	Hub (R)	82 03 257	82 03 257	82 03 257	82 03 257
18	Raschiapolvere	Dust	82 03 258	82 03 258	82 03 258	82 03 258
19	Tubo interno forcella	Tube	82 03 259	82 03 259	82 03 259	82 03 259
20	Pompante completo	Pumping device compl.	82 03 260	82 03 260	82 03 260	82 03 260
21	Boccola guida completa	Bush	82 03 261	82 03 261	82 03 261	82 03 261
22	Molla	Spring	82 03 262	82 03 262	82 03 262	82 03 262
23	Puntale	Ferrule	82 03 263	82 03 263	82 03 263	82 03 263
24	Paracolpo	Plug	82 03 264	82 03 264	82 03 264	82 03 264
25	Vite fissaggio pompante	Screw	82 03 265	82 03 265	82 03 265	82 03 265
26	Rondella vite fissaggio pompante	Washer	82 03 266	82 03 266	82 03 266	82 03 266
27	Ghiera di fissaggio	Ring nut	81 03 440	81 03 440	81 03 440	81 03 440
28	Rondella ferma boccola	Washer	81 03 391	81 03 391	81 03 391	81 03 391
29	Anello di tenuta forcella	O ring	81 03 199	81 03 199	81 03 199	81 03 199
30	Bussola superiore fodero	Bush	81 03 393	81 03 393	81 03 393	81 03 393

CR1



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Cablaggio principale	Wiring harness	82 12 206	82 12 206	82 12 206	82 12 206
2	Dispositivo avv. el. con cavetto	Electric start switch with cable	82 12 109	82 12 109	—	—
3	Devoluti sx con cablaggio	Light control device	82 12 199	82 12 199	82 12 199	82 12 199
4	Cablaggio fanale posteriore	Tail light wires	81 12 424	81 12 424	81 12 424	81 12 424
5	Fanale posteriore	Tail light compl.	82 12 103	82 12 103	82 12 103	82 12 103
6	Regolatore di tensione	Voltage regulator	82 12 121	82 12 121	82 12 121	82 12 121
7	Relé avviamento	Starter relay	82 12 085	82 12 085	—	—
8	Blocchetto portafusibili/diodo	Fuse box	82 12 143	82 12 143	82 12 143	82 12 143
9	Fusibile 7,5 A	Fuse 7,5 A	81 12 244	81 12 244	81 12 244	81 12 244
10	Intermittenza indicatori	Intermittence	81 12 040	81 12 040	81 12 040	81 12 040
11	Supporto cicalina	Intermittence holder	82 12 165	82 12 165	82 12 165	82 12 165
12	Claxon	Horn	82 12 228	82 12 228	82 12 228	82 12 228
13	Indicatore di direzione ant. dx	Front flasher light (R)	81 12 665		82 12 210	82 12 210
14	Indicatore di direzione ant. sx	Front flasher light (L)				
15	Indicatore di direzione post. dx	Rear flasher light (R)	82 12 210	82 12 210	82 12 210	82 12 210
16	Indicatore di direzione post. sx	Rear flasher light (L)	82 12 209	82 12 209	82 12 209	82 12 209
17	Trasduttore elettronico	Electr. transducer	82 12 119	82 12 119	82 12 119	82 12 119
18	Batteria 12V 4 AH	Battery 12V 4 AH	82 12 110	82 12 110	82 12 110	82 12 110
19	Cavetto massa-batteria	Mass battery cable	82 12 203	82 12 203	82 12 203	82 12 203
20	Cablaggio batteria relé	Battery relay cable	82 12 204	82 12 204	—	—
21	Cablaggio relé - motorino	Relay cable - starter engine	82 12 205	82 12 205	—	—
22	Cablaggio fanali anteriori	Double headlight wires	82 12 142	82 12 142	82 12 142	82 12 142
23	Fanale anteriore senza cuffie	Headlight compl.	82 12 139	82 12 139	82 12 139	82 12 139
24	Pomello regolazione doppio fanale	Adjusting knob	82 20 212	82 20 212	82 20 212	82 20 212
25	Molla doppio fanale	Spring	81 03 701	81 03 701	81 03 701	81 03 701
26	Portalamпада bifaro	Front lamp holder	82 12 188	82 12 188	82 12 188	82 12 188
27	Termistore per termometro acqua	Thermistor water gauge	82 22 019	82 22 019	82 22 019	82 22 019
28	Interruttore stop completo	Rear brake switch	81 12 086	81 12 086	81 12 086	81 12 086
29	Passacavo	Fair lead	81 20 512	81 20 512	81 20 512	81 20 512
30	Molla interruttore stop	Spring	82 21 013	82 21 013	82 21 013	82 21 013
31	Elastico fiss. batteria	Battery elastic	81 20 272	81 20 272	81 20 272	81 20 272
32	Gancio fiss. batteria	Battery elastic hook	81 01 313	81 01 313	81 01 313	81 01 313
33	Gommino	Rubber	81 20 482	81 20 482	81 20 482	81 20 482
34	Vetro fanale posteriore	Tail light glass	82 12 124	82 12 124	82 12 124	82 12 124
35	Bussola appoggio fanale	Bush	82 21 060	82 21 060	82 21 060	82 21 060
36	Gommino	Rubber	82 20 150	82 20 150	82 20 150	82 20 150
37	TRASPARENTE FRECCIA		81 12 264			



POS. N.	DESCRIZIONE	DESCRIPTION	TUAREG 50-88 A.E. I.M. "A"		TUAREG 50-80 K.S. I.M. "A"	
			BLU-BLUE	VERDE-GREEN	BLU-BLUE	VERDE-GREEN
1	Volano magnete completo di corona	Fly wheel magneto, compl.	82 22 081	82 22 081	82 22 059	82 22 059
2	Motorino avviamento elettrico	Starter compl.	82 22 058	82 22 058	—	—
3	Carcassa completa	Starter compl. motor case	82 22 062	82 22 062	—	—
4	Supporto lato collettore	Holder	82 22 065	82 22 065	—	—
5	Indotto	Rotor	82 22 063	82 22 063	—	—
6	Rinvio completo	Driving gear	82 22 064	82 22 064	—	—
7	Supporto lato pignone	Holder	82 22 068	82 22 068	—	—
8	Serie rosette e spazzole	Brushes with screw and nuts	82 22 066	82 22 066	—	—
9	Spazzola	Brush	82 22 067	82 22 067	—	—
10	FASCETTA ATTACCO MOT. AVV.		82.01.261	82.01.261		


CENTRO RICAMBI^{SRL}
via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
e-mail: cr1firenze@tiscali.it

TUAREG

Wind



- VARIANTI -

**CATALOGO
RICAMBI**

**SPARE PARTS CATALOG
CATALOGUE RECHANGES
ERSATZTEILKATALOG**


TUAREG 50/89

aprilia

209/1

1989






POS. N.	DESCRIZIONE	DESCRIPTION	T.G.	TUAREG 50 I.M."A"	
				BLU-BLUE	ROSSO-RED
1	Telaio verniciato	Frame	6.8	82 32 427	82 32 427
2	Cavallotto laterale	Lateral stand	0.2	82 32 428	82 32 428
3	Forcellone verniciato	Rear swing arm	0.8	82 32 302	82 32 302
4	Motore	Engine	1.3	82 22 153	82 22 153
5	Marmitta verniciata	Exhaust pipe	0.4	82 19 073	82 19 073
6	Silenziatore	Silencer	0.2	82 19 083	82 19 083
7	Radiatore acqua	Radiator	0.6	82 04 006	82 04 006
8	Paramani dx-sx	Hand guard		82 30 447	82 30 401
9	Cavo frizione	Clutch cable		82 14 055	82 14 055
10	Indicatore direzione ant.	Front flasher light		81 12 665	81 12 665
11	Vetro freccia	Flasher light glass		81 12 674	81 12 674
12	Serbatoio benz. vern.	Fuel tank	0.3	82 30 448	82 30 360
13	Sella	Seat		(BLU) 82 29 054	82 29 047 (ROSSA)
14	Fiancatina dx verniciata	Side panel (R)	0.2	82 30 362	82 30 362
15	Fiancatina sx verniciata	Side panel (L)	0.2	82 30 364	82 30 364
16	Borsello porta attrezzi	Gloves case		82 01 268	82 01 327
17	Carena completa verniciata	Fairing compl.	0.3	82 30 449	82 30 368
18	Parafango posteriore	Rear mudguard	0.3	82 26 080	82 26 080
19	Decalco (serie)	Decal (set)		82 11 709	82 11 681
20	Rete doppi fari	Headlight screen		82 30 314	82 30 370


CENTRO RICAMBI ^{SRL}

via CIMABUE, 24/A - 50121 FIRENZE (ITALY)
 TEL. (+39) 055-66 64 23 - FAX (+39) 055-67 00 84
 e-mail: cr1firenze@tiscali.it



POS. N.	DESCRIZIONE	DESCRIPTION	T.G.	TUAREG 50 I.M. "A"	
				BLU-BLUE	ROSSO-RED
1	Forcella	Front fork	0.8	82 03 278	82 03 278
2	Anello parapolvere inferiore	Ring dust cover		81 01 271	81 01 271
3	Anello supporto parapolvere			81 01 272	81 01 272
4	Cuscinetto a rulli	Roller Bearing	1.1 (x2)	81 10 024	81 10 024
5	Cuscinetto a sfere	Ball	0.8	81 10 025	81 10 025
6	Parapolvere superiore	Upper dust cover		81 20 211	81 20 211
7	Supporto dx paraf. ant. anodizzato	Supporter (L.)		81 32 666	81 32 666
8	Supporto sx paraf. ant. anodizzato	Supporter (R.)		81 32 667	81 32 667
9	Cavallotto manubrio	U bolt		82 03 040	82 03 040
10	Piastra superiore	Upper plate		82 03 295	82 03 295
11	Dado Fissaggio cannotto	Nut washer		82 03 147	82 03 147
12	Rondella dado fissaggio cannotto	Lower plate		81 52 032	81 52 032
13	Piastra inferiore con cannotto			82 03 294	82 03 294
14	Fodero	Fork leg	0.8	82 03 290	82 03 290
15	Stelo sx	Tube (L)	1.1	82 03 292	82 03 292
16	Fondello sx	Hub (L)		82 03 291	82 03 291
17	Fondello dx	Hub (R)		82 03 302	82 03 302
18	Paraolio	Oil seal	1.0	81 03 687	81 03 687
19	Vite tappo forcella	Screw washer		81 03 985	81 03 985
20	Rondella per vite tappo forcella			82 05 050	82 05 050
21	Tappo fodero	Plug		82 03 289	82 03 289
22	Anello di tenuta	O ring	0.9	81 03 987	81 03 987
23	Gruppo cartuccia	Cartridge		82 03 303	82 03 303
24	Anello di tenuta	O ring		82 03 293	82 03 293
25	Vite fissaggio manubrio	Screw		82 05 057	82 05 057
26	Distanziale	Spacer		82 03 296	82 03 296
27	Rondella	Washer		81 03 994	81 03 994
28	Gommino battuta	Rubber		81 03 995	81 03 995
29	Molla	Spring		82 03 297	82 03 297
30	Asta molla	Rod		82 03 298	82 03 298
31	Molla	Spring		82 03 299	82 03 299
32	Distanziale	Spacer		82 03 300	82 03 300
33	Stelo dx	Tube (R)	1.1	82 03 301	82 03 301
34	Vite fissaggio steli-piastre	Screw		82 05 053	82 05 053